CONTENTS

JAECOO 7 ICE Disassembly Manual

Section 1 Introduction

CONTENTS

Page

Overview	3
Introduction to Relevant Laws and Regulations	4
Term Explanation	5
General Description	
Disassembly Site and Equipment	8
Safety Warning Description	

Overview

Overview Content

The compilation of the "Disassembly Manual" aims to ensure the environmentally friendly disposal of end-of-life vehicles, assist and guide recycling and disassembly enterprises to efficiently and safely complete disassembly operations, handle waste in a scientific and environmentally friendly manner, enhance the environmental protection standards and recycling capabilities of end-of-life vehicle recycling and disassembly enterprises, while simultaneously increasing the recycling rate of end-of-life vehicles and reducing the potential for harm to the environment and personnel during the disassembly process.

Dear user, this disassembly manual is applicable to the JAECOO 7 ICE. The images and instructions with specified models in this manual are only valid for this vehicle model. Therefore, please make sure to confirm the vehicle model by referring to the model number in the table before proceeding with the disassembly.

Generic Name	JEACOO 7
English Name of Vehicle Model	JEACOO 7
Year of Launch	2024
Applicable Model	JAECOO 7 ICE
Length/Width/Height (mm)	4500/1865/1680
Wheel Base (mm)	2672
Luggage Compartment Capacity (L)	350
Tire Size	235/50 R19
Curb Weight (kg)	1544
Transmission Type	7DCT
Fuel Type	Gasoline
Drive Mode	Front Wheel Drive

Detailed Information of Vehicle Model

Introduction to Relevant Laws and Regulations

EU RRR Relevant Directive Requirements

EU Directive 2000/53/EC on End-of-Life Vehicles

Requirements for reuse, recycling and recovery under Article 7 of the End-of-Life Vehicles Directive by the European Parliament and the Council of the European Union:

- Before January 1, 2006, the average reuse and recovery rate of all end-of-life vehicles should be at least 85%. During the same period, the average reuse and recycling rate should be at least 80%. For vehicles produced before January 1, 1980, the average reuse and recycling rate must not be less than 75%; the average reuse and recovery rate must not be less than 70%.
- Before January 1, 2015, the average reuse and recycling rate of all end-of-life vehicles should be at least 95%; during the same period, the average reuse and recovery rate should be at least 85%.

EU 2005/64/EC Directive Requirements

According to Annex I of the amended Directive 70/156/EEC of the European Parliament and the Council regarding the reusability, recyclability and recoverability of automobiles, M1 class vehicles shall meet the following requirements:

- The weight of reuse and/or recycling must account for at least 85% of the total vehicle weight;
- The weight of recovery must account for at least 95% of the total vehicle weight.

The European Union has banned or restricted the use of lead, mercury, cadmium, or hexavalent chromium in automotive materials or components placed on the market after July 1, 2003, with certain exemptions allowed. Directive 2011/37/EU (Annex II of Directive 2000/53/EC) lists the vehicle materials or components exempted from Article 4(2)(a) of Directive 2000/53/EC. Materials or components containing lead, mercury, cadmium, or hexavalent chromium are allowed in vehicles placed on the market before the exemption dates.

Term Explanation

1. End of Life Vehicles (ELVs)

Vehicles that have met the criteria for mandatory scrapping as stipulated by national standards or are no longer in use (or are requested to be discarded) by their owners.

2. Dismantling Information

Guidance information provided by manufacturers for the proper and environmentally friendly disposal of end-of-life vehicles.

3. Removal

The process and manner for end-of-life vehicles involve conducting non-hazardous disposal, disassembly reusable components and major assemblies; separating and storing items based on their material types; and flattening or cutting the vehicle body and structural parts.

4. Disassembly/Dismantling

The process of disassembly vehicles, assemblies, components, or other parts.

5. Reuse

Any use of end-of-life vehicle parts for their intended design purpose.

6. Recycling

Through reprocessing of waste materials, they can be made to meet their original usage requirements or be used for other purposes, excluding processes that generate energy from them.

7. Recvery

Through reprocessing of waste materials, they can be made to meet their original usage requirements or be used for other purposes, including processes that generate energy from them.

8. Prohibited Substances

Substances that pose a hazard or potential risk to human health, animal and plant life safety, and the environment, and are present in automotive products within a certain concentration limit.

9. Vehicle Materials

The collective term for various materials that constitute vehicle products and components, including metallic materials, non-metallic materials, and composite materials. Based on their usage, they are divided into manufacturing materials and operational materials. Manufacturing materials are the various materials that constitute vehicles and components, while operational materials refer to the materials consumed during the use of vehicles.

10. Pretreatment

During the disassembly of end-of-life vehicles, the first step is to handle and collect toxic and hazardous components or materials that are prone to causing environmental pollution or personal injury. It mainly includes the following vehicle components and/or materials:

All liquids (including fuel, engine lubricating oil, transmission/gearbox (including rear differential and/ or transfer case) oil, power steering oil, coolant, brake fluid, shock absorber fluid, air conditioning

refrigerant, windshield washer fluid, and hydraulic suspension fluid, etc.), airbags, batteries, oil filters, liquefied petroleum gas (LPG) tanks, compressed natural gas (CNG) tanks, tires, catalytic converters, etc.

General Description

Disassembly Requirements

Disassembly must comply with the corresponding national laws and regulations, in accordance with environmental, health, and worker protection regulations, which cover all tasks, including handling, sorting, transportation, storage, and other methods for the disposal of parts, chemicals, filters, and other materials. Disassembly should prioritize the protection of land and surface water resources to avoid contamination. Hazardous and toxic substances should be handled in well-ventilated areas in accordance with the requirements of the corresponding laws and regulations. Staff must be familiar with and respect the corresponding safety instructions. Hazardous waste materials after disassembly should be transported to locally approved waste disposal sites. According to the corresponding standards and requirements, all working fluids and specified parts and assemblies must be removed first. Relevant large parts/assemblies must be easily removable, and all working fluids should be fully extracted as much as possible;

Remove the following parts before disassembling the vehicle

- Separate the battery;
- Separate or neutralize components with potential explosion hazards, such as airbags and seat belt pretensioners;
- Separate all components and those verified to contain mercury;
- Separate metal components containing copper, aluminum, and magnesium before they are separated by scrap car shredders;
- Separate tires and large plastic components (such as shock absorbers, instrument panels, liquid containers, etc.) before they are separated by scrap car shredders, as they can be directly converted into raw materials for recycling;
- Separate the glass

Extract Liquids

• Separate and store coolant, antifreeze, brake fluid, air conditioning refrigerant, and other liquids contained in end-of-life vehicles. These liquids must be stored separately for reuse.

Dismantle other components as required.

Disassembly Site and Equipment


Disassembly Site

- The operating area should be no less than 10,000m², with the working area (including storage and disassembly sites) covering no less than 6,000m²
- The ground of the end-of-life vehicle storage area (including temporary storage) should be hardened and impermeable
- The disassembly site should be an enclosed or semi-enclosed workshop with a floor that prevents leakage. The disassembly workshop should be well-ventilated and well-lit, with complete safety prevention facilities, and located far away from residential areas
- A warehouse for used parts should be set up
- The main drainage outlets of the storage area and disassembly workshop should be equipped with oil-water separators and connected to drainage ditches

Facilities and Equipment

- Equipped with vehicle weighing equipment.
- Equipped with an indoor disassembly pretreatment platform, along with dedicated waste liquid collection devices and specialized, sealed containers for the classified storage of various waste liquids.
- Equipped with a refrigerant collection device for automotive air conditioning.
- Equipped with containers for the classified storage of capacitors and batteries containing polychlorinated biphenyls or polychlorinated terphenyls.
- Equipped with frame cutting equipment, body shortening or flattening equipment.
- Equipped with lifting and transportation equipment.
- Equipped with an assembly disassembly platform or a detailed disassembly platform.
- There should be no less than 5 professional technicians, whose professional skills should meet the corresponding requirements for standardized disassembly, environmental protection operations, and safe operations (including the collection, storage, and transportation of hazardous substances). Operators in relevant positions should comply with national regulations requiring certification for employment and hold the necessary licenses if stipulated by law.
- Equipped with office facilities such as computers.
- Equipped with fire-fighting facilities that comply with relevant national regulations.

Detailed example photos of disassembly equipment are provided in the images. Enterprises may appropriately add equipment and tools that are not listed according to their own needs.





Trolley




Vehicle Disassembly Tool


General Disassembly Tool

- Open-end wrench Can be used for standard bolts and nuts.
- TORX wrench Suitable for assembling and disassembling bolts and nuts in confined spaces. It can be used for standard bolts and nuts, especially when a larger torque is required for assembling or disassembling, making it the preferred choice for such tasks.
- Socket wrench Can be used for standard bolts and nuts. It is appropriate for assembling and disassembling bolts and nuts in both general locations and those in deep, recessed, or concealed narrow spaces. When paired with extension bars, it can speed up the process.
- Torque wrench Generally used for assembling and disassembling bolts and nuts that require a specific tightening torque, such as those on cylinder heads, crankshaft main bearing caps, and connecting rod caps.
- Adjustable wrench Generally used for assembling and disassembling bolts and nuts of different sizes.
- Pipe wrench Used for turning metal pipe fittings or other cylindrical workpieces.
- Screwdriver (flat tip and cross tip) Used for assembling and disassembling screws.
- Saw Used for cutting metal wires, bending small parts and plastics, etc.
- Crowbar Used to avoid direct contact between the hammer and the vehicle body, protecting the vehicle body from damage during assembly and disassembly.
- Puller Used for removing tightly fitted components such as bearings and gears.


Example photos of general disassembly tools are provided in the illustration




45-Piece Vehicle Disassembly Tool Set




Vise






Wire Stripper





Crowbar Combination


Adjustable Wrench




Screwdriver Set

18-Piece Socket Set


Example photos of protective equipment and some specialized tools are provided in the illustration




Protective Goggles




Dual-purpose Filter Wrench



Ball Joint Puller



Electric Soldering Iron



Gas Mask

Technical Requirements for Disassembly

- Directly detonate the airbag or detonate after removing safety components
- Use special tools and containers to empty and collect waste liquid in the vehicle
- Use special equipment to recover the refrigerant of automobile air conditioning, with different refrigerants being recovered separately
- When disassembling end-of-life automotive parts, appropriate special tools should be used to ensure the reusability of the parts and the recyclability of materials as much as possible
- Reusable parts that have been removed should be stored indoors
- Containers for storing various parts, materials, and waste should be labeled to avoid mixing and commingling
- Solid waste should be handed over to waste disposal units that meet relevant national standards for processing, and must not be incinerated or discarded

Safety Warning Description

Safety Warning Sign Description Icon

Sign Type	Sign	Text Description
		This symbol indicates that the part/assembly is explosive.
Warni-		This symbol indicates that the part/assembly is a toxic and hazardous chemical.
ng Sign		This symbol indicates that the part/assembly is flammable.
		This symbol indicates that the part/assembly is corrosive.

		This icon indicates that a protective helmet must be worn during disassembly.
		This icon indicates that protective goggles must be worn during disassembly.
Instruc- tion Sign		This icon indicates that ear protectors must be worn during disassembly.
		This icon indicates that protective gloves must be worn during disassembly.
	R	This icon indicates that protective footwear must be worn during disassembly.


Section 2 Vehicle Disassembly Instructions

CONTENTS	Page
Detailed Process and Instructions	

Detailed Process and Instructions

2.1 Pretreatment

2.1.1 Driver Airbag Assembly




Driver airbag assembly:

Applicable Model	JAECOO 7
Position Description	Center of steering wheel
Quantity	1
Weight (Kg)	0.92
Main Material	ТРО
Fastener	Clip
Number of Fasteners	3
Disassembly Tool	Flat tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	The deployed airbag can be crushed, sorted, and reused.
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment



2.1.2 Front Passenger Airbag Assembly




Front passenger airbag assembly:

Applicable Model	JAECOO 7
Position Description	On the instrument panel crossmember
Quantity	1
Weight (Kg)	1.58
Main Material	PA66
Fastener	Screw, nut
Number of Fasteners	4
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	The deployed airbag can be crushed, sorted, and reused.
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment



2.1.3 Left Curtain Shield Airbag Assembly




Left curtain shield airbag assembly:

Applicable Model	JAECOO 7
Position Description	On the left B-pillar trim panel
Quantity	1
Weight (Kg)	1.258
Main Material	PA66
Fastener	Bolt, clip
Number of Fasteners	11
Disassembly Tool	Socket wrench, clip remover
Disassembly Method	After safe deployment, loosen the fasteners for disassembly
Recycling Pathways	The deployed airbag can be crushed, sorted, and reused.
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment




2.1.4 Right Curtain Shield Airbag Assembly



Right curtain shield airbag assembly:

Applicable Model	JAECOO 7
Position Description	On the right B-pillar trim panel
Quantity	1
Weight (Kg)	1.258
Main Material	PA66
Fastener	Bolt, clip
Number of Fasteners	11
Disassembly Tool	Socket wrench, clip remover
Disassembly Method	After safe deployment, loosen the fasteners for disassembly
Recycling Pathways	The deployed airbag can be crushed, sorted, and reused.
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment



2.1.5 Front Left Airbag Assembly


PP PE PE
PVC PA
ABS PMMA
PUR GLASS
OTHER

JAECOO 7
Inside the driver seat
1
0.4
PA66
Nut
1
Socket wrench
After safe deployment, loosen the fasteners for disassembly
The deployed airbag can be crushed, sorted, and reused.
Wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment

Front left airbag assembly:



2.1.6 Front Right Airbag Assembly



Front right airbag assembly:

Applicable Model	JAECOO 7
Position Description	Inside the front passenger seat
Quantity	1
Weight (Kg)	0.4
Main Material	PA66
Fastener	Nut
Number of Fasteners	1
Disassembly Tool	Socket wrench
Disassembly Method	After safe deployment, loosen the fasteners for disassembly
Recycling Pathways	The deployed airbag can be crushed, sorted, and reused.
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment




2.1.7 Front Left Seat Belt Assembly


PP PE PE
PVC PA
 ABS PMMA
PUR GLASS
OTHER

Front left seat belt assembly:

Applicable Model	JAECOO 7
Position Description	Lower side of left B-pillar
Quantity	1
Weight (Kg)	1.49
Main Material	QSTE500TM, polyester
Fastener	Bolt
Number of Fasteners	3
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Recycling and reuse of waste fiber products; Melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.1.8 Front Right Seat Belt Assembly




Front right seat belt assembly:

Applicable Model	JAECOO 7
Position Description	Lower side of right B-pillar
Quantity	1
Weight (Kg)	1.49
Main Material	QSTE500TM, polyester
Fastener	Bolt
Number of Fasteners	3
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Recycling and reuse of waste fiber products; Melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.1.9 Rear Seat Belt Assembly





Rear seat belt assembly:

Applicable Model	JAECOO 7
Position Description	On C-pillar sheet metal
Quantity	3
Weight (Kg)	4.11
Main Material	QSTE500TM, polyester
Fastener	Bolt
Number of Fasteners	5
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Recycling and reuse of waste fiber products; Melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.1.10 Battery





Battery:

Battery.	
Applicable Model	JAECOO 7
Position Description	Right side of the engine compartment
Quantity	1
Weight (Kg)	20.8
Main Material	PP, sulfuric acid, lead, water
Fastener	Nut
Number of Fasteners	2
Disassembly Tool	Socket wrench
Disassembly Method	tep 1: Remove the nuts from the positive and negative terminals of the battery and take off the positive and negative cables. Step 2: Remove the nuts from the pressure plate and take out the pull rod and pressure plate. Step 3: Remove the battery.
Recycling Pathways	Deliver to battery recycling companies for disposal
Precautions for Disassembly	Avoid contact of acid with skin and eyes to prevent burns; it is highly flammable, so keep away from fire sources; it is a toxic substance, so prevent skin contact; avoid direct exposure of the battery to sunlight; wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment.



Caution:

Batteries contain highly corrosive liquids. Removal personnel should wear protective clothing and goggles to avoid contact of the acid with skin and eyes. No open flames, electrical sparks, bright lights, or smoking are allowed. Prevent the battery casing from being exposed to ultraviolet rays and do not allow the battery to be exposed to sunlight. Before removing the battery, it is necessary to turn off ignition switch and all electrical appliances, and first disconnect the negative cable, followed by the positive cable. Batteries are flammable, explosive, and toxic substances.

PP PE PVC PA ABS PMMA PUR GLASS

2.1.11 Tire Pressure Sensor Battery

Pressure sensor battery:

Applicable Model	JAECOO 7
Position Description	Among the four tires
Quantity	4
Weight (Kg)	0.03/pc
Main Material	PA66
Fastener	No
Number of Fasteners	No
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Deliver to battery recycling companies for disposal
Precautions for Disassembly	It is highly flammable, so keep away from fire sources; wear protective equipment (goggles, gloves, etc.)



2.1.12 Remote Controller Battery

A CONTRACT OF A	
	C C
	PP PE PE
	PVC PA
	ABS PMMA
	PUR GLASS
	OTHER


Remote controller battery:

Applicable Model	JAECOO 7
Position Description	Inside the key housing
Quantity	1
Weight (Kg)	-
Main Material	Lithium battery
Fastener	Metal clip inside the key
Number of Fasteners	-
Disassembly Tool	-
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Deliver to battery recycling companies for disposal
Precautions for Disassembly	It is highly flammable, so keep away from fire sources; it is a toxic substance, so prevent skin contact;



2.1.12 Gasoline






Gasoline:

Applicable Model	JAECOO 7
Position Description	Inside the fuel tank
Quantity	1
Weight (Kg)	-
Main Material	Gasoline
Fastener	Nut
Number of Fasteners	1
Disassembly Tool	Evacuation and suction equipment
Disassembly Method	Unscrew the fuel filler port and use the evacuation and suction equipment to drain
Recycling Pathways	Deliver to qualified waste oil recycling companies for disposal
Precautions for Disassembly	It is highly flammable, so keep away from fire sources; wear protective equipment (goggles, gloves, etc.)



2.1.13 Engine Oil




Engine oil:

Applicable Model	JAECOO 7
Position Description	Inside the engine
Quantity	1
Weight (Kg)	-
Main Material	Engine Oil
Fastener	-
Number of Fasteners	-
Disassembly Tool	Evacuation and suction equipment
Disassembly Method	Unscrew the fuel filler port and use the evacuation and suction equipment to drain
Recycling Pathways	Deliver to qualified waste oil recycling companies for disposal
Precautions for Disassembly	It is highly flammable, so keep away from fire sources; wear protective equipment (goggles, gloves, etc.)



2.1.14 Transmission Oil






Transmission oil:

Applicable Model	JAECOO 7
Position Description	Inside the transmission
Quantity	1
Weight (Kg)	-
Main Material	Transmission Oil
Fastener	-
Number of Fasteners	-
Disassembly Tool	Evacuation and suction equipment
Disassembly Method	Unscrew the fuel filler port and use the evacuation and suction equipment to drain
Recycling Pathways	Deliver to qualified waste oil recycling companies for disposal
Precautions for Disassembly	It is highly flammable, so keep away from fire sources; wear protective equipment (goggles, gloves, etc.)




2.1.15 Coolant





Coolant:

Applicable Model	JAECOO 7
Position Description	In the components related to the cooling system
Quantity	1
Weight (Kg)	-
Main Material	Coolant
Fastener	-
Number of Fasteners	-
Disassembly Tool	Evacuation and suction equipment
Disassembly Method	Unscrew the fuel filler port and use the evacuation and suction equipment to drain
Recycling Pathways	Deliver to qualified coolant recycling companies for disposal
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment




2.1.16 Brake Fluid






Brake fluid:

Applicable Model	JAECOO 7			
Position Description	In the brake fluid reservoir and brake lines			
Quantity	1			
Weight (Kg)	-			
Main Material	Brake fluid			
Fastener	-			
Number of Fasteners	-			
Disassembly Tool	Evacuation and suction equipment			
Disassembly Method	Unscrew the fuel filler port and use the evacuation and suction equipment to drain			
Recycling Pathways	Deliver to qualified waste fluid recycling companies for disposal			
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment			



2.1.17 Shock Absorber Oil





Shock absorber oil:

Applicable Model	JAECOO 7			
Position Description	Inside the shock absorber			
Quantity	Front shock absorber 2, rear shock absorber 2			
Weight (Kg)	-			
Main Material	Shock absorber oil			
Fastener	-			
Number of Fasteners	-			
Disassembly Tool	Evacuation and suction equipment			
Disassembly Method	Unscrew the fuel filler port and use the evacuation and suction equipment to drain			
Recycling Pathways	Deliver to qualified waste fluid recycling companies for disposal			
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)			




2.1.18 Windshield Washer Fluid






Windshield washer fluid:

Applicable Model	JAECOO 7			
Position Description	Washer fluid reservoir			
Quantity	1			
Weight (Kg)	-			
Main Material	Windshield washer fluid			
Fastener	-			
Number of Fasteners	-			
Disassembly Tool	Evacuation and suction equipment			
Disassembly Method	Unscrew the fuel filler port and use the evacuation and suction equipment to drain			
Recycling Pathways	Deliver to qualified waste fluid recycling companies for disposal			
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)			



2.1.19 R134a Refrigerant




R134a refrigerant:

Applicable Model	JAECOO 7			
Position Description	Inside the high/low pressure pipes of the A/C			
Quantity	1			
Weight (Kg)	-			
Main Material	Refrigerant			
Fastener	-			
Number of Fasteners	-			
Disassembly Tool	Refrigerant discharging device			
Disassembly Method	Use specialized refrigerant equipment for discharging			
Recycling Pathways	Deliver qualified refrigerant recycling companies for disposal			
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.); operate in a well-ventilated environment; it is a toxic substance, so prevent skin contact			




2.1.20 Precatalytic Converter



Precatalytic converter:

-	
Applicable Model	JAECOO 7
Position Description	Underbody
Quantity	1
Weight (Kg)	4.34
Main Material	SUS441, cordierite
Fastener	Bolt, nut
Number of Fasteners	3, 5
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.1.21 Oil Filter


PP PE PVC PA ABS PMMA PUR GLASS OTHER I				
ABS PMMA PUR GLASS		PP	PE	
ABS PMMA PUR GLASS		PVC	PA	
PUR GLASS GLASS			PMMA	
OTHER OTHER			GLASS	
		OTHER		


Oil filter:

Applicable Model	JAECOO 7			
Position Description	Inside the engine compartment			
Quantity	1			
Weight (Kg)	111.2			
Main Material	Aluminium alloy			
Fastener	Bolt, nut			
Number of Fasteners	18			
Disassembly Tool	Socket wrench			
Disassembly Method	Loosen the fasteners for disassembly			
Recycling Pathways	Melting and reuse of metal materials			
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)			




2.1.22 Fuel Filter






Fuel filter:

JAECOO 7			
Inside the electric fuel pump			
1			
1			
POM, SUS304			
-			
-			
Socket wrench			
Loosen the fasteners for disassembly			
Modified recycling of waste plastics; melting and reuse of metal materials			
Wear protective equipment (goggles, gloves, etc.)			



2.1.23 Tire





Tire:

JAECOO 7				
Front/rear/left/right of the vehicle body				
4				
12.35/pc				
Rubber				
Bolt				
5 for each tire				
Pneumatic wrench, vehicle lift, tire changer				
Use a pneumatic wrench to remove the retaining bolts, and then remove the tire and hub; use tire dismantling equipment such as a tire changer to remove the tire				
Reuse of crumb rubber made from waste rubber; reuse of reclaimed rubber from waste rubber				
Wear protective equipment (goggles, gloves, etc.)				




2.1.24 Spare Tire






Spare tire:

Applicable Model	JAECOO 7			
Position Description	Inside the luggage compartment			
Quantity	4			
Weight (Kg)	5.43			
Main Material	Rubber			
Fastener	-			
Number of Fasteners	-			
Disassembly Tool	-			
Disassembly Method	Remove directly			
Recycling Pathways	Reuse of crumb rubber made from waste rubb reuse of reclaimed rubber from waste rubber			
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)			



2.2 Removal

2.2.1 Front Bumper



Front bumper:

Applicable Model	JAECOO 7
Position Description	Front bumper is located at the front of vehicle
Quantity	1
Weight (Kg)	5.893
Main Material	PP+EPDM-T20
Fastener	Bolt, screw
Number of Fasteners	7
Disassembly Tool	Socket wrench, cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.2 Front Bumper Lower Spoiler Assembly


	PP		PE	
	PVC		PA	
	ABS		PMMA	
	PUR		GLASS	
	OTHER			

Front bumper lower spoiler assembly:

Applicable Model	JAECOO 7
Position Description	On the front bumper
Quantity	1
Weight (Kg)	0.5
Main Material	PP+EPDM-T20
Fastener	Screw
Number of Fasteners	4
Disassembly Tool	Cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.3 Front Bumper Lower Protector Assembly




Front bumper lower protector assembly:

Applicable Model	JAECOO 7
Position Description	On the front bumper
Quantity	1
Weight (Kg)	1.2
Main Material	PP+EPDM-T20
Fastener	Screw
Number of Fasteners	6
Disassembly Tool	Cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.4 Rear Bumper




Rear bumper:

Applicable Model	JAECOO 7
Position Description	Rear bumper is located at the rear of vehicle
Quantity	1
Weight (Kg)	6.4
Main Material	PP+EPDM-T20, ABS
Fastener	Bolt, screw
Number of Fasteners	11
Disassembly Tool	Socket wrench, cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.5 Intake Grille




Intake grille:

Applicable Model	JAECOO 7
Position Description	Located at the front of vehicle
Quantity	1
Weight (Kg)	3.92
Main Material	PMMA+ASA, PP+GF30
Fastener	Bolt
Number of Fasteners	6
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.6 Wheel Hub Outer Cover



Wheel hub outer cover:

Applicable Model	JAECOO 7
	3/(2000 /
Position Description	Wheel hub outer covers are located at the center of four wheels
Quantity	1
Weight (Kg)	0.017/pc
Main Material	ABS; aluminum Sheet; SUS 304
Fastener	-
Number of Fasteners	-
Disassembly Tool	Flat tip screwdriver
Disassembly Method	Remove directly
Recycling Pathways	Modified recycling of waste plastics; melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.7 Fuel Filler Cap


PP PE PE			
PVC PA			
ABS PMMA			
PUR GLASS			
OTHER			

Fuel filler cap:

Applicable Model	JAECOO 7
Position Description	Fuel filler cap is located above the rear left wheel
Quantity	1
Weight (Kg)	0.13
Main Material	PA66+PPE
Fastener	-
Number of Fasteners	-
Disassembly Tool	-
Disassembly Method	-
Recycling Pathways	Modified recycling of waste plastics; recycling of mixed plastics through crushing and separation
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.8 Front Windshield Lower Trim Panel




Front windshield lower trim panel:

Applicable Model	JAECOO 7
Position Description	Under the front windshield
Quantity	1
Weight (Kg)	1.17
Main Material	PP-T20, PU
Fastener	Screw
Number of Fasteners	5
Disassembly Tool	Cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; reuse of rigid polyurethane foam through blending modification
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.9 A-pillar Trim Panel Assembly




A-pillar trim panel assembly:

Applicable Model	JAECOO 7
Position Description	On the body A-pillar
Quantity	1
Weight (Kg)	0.56/pc
Main Material	ASAXC230G; PC+ABS; ASA; TPV-(EPDM+PP)
Fastener	Clip
Number of Fasteners	14
Disassembly Tool	Clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; recycling of mixed plastics through crushing and separation
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.10 Front Splash Guard



Front splash guard:

Applicable Model	JAECOO 7
Position Description	The bottom of the engine
Quantity	1
Weight (Kg)	1.06
Main Material	PP/GF 60/40; PET; PP
Fastener	Bolt, clamp, screw
Number of Fasteners	11
Disassembly Tool	Socket wrench, cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; recycling of mixed plastics through crushing and separation
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.11 Front Wheel Arch Ornament Assembly

	PP		PE		
	PVC		PA		
4	ABS		PMMA		
•	PUR		GLASS		
	OTHER				

Front wheel arch ornament assembly:

Applicable Model	JAECOO 7
Position Description	Front wheel archs are located at the front of vehicle, above the two front wheels
Quantity	1 on each side
Weight (Kg)	0.38/pc
Main Material	ABP-2019
Fastener	Screw, clip
Number of Fasteners	12
Disassembly Tool	Cross tip screwdriver, clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.12 Rear Wheel Arch Ornament Assembly

			6	
	PP		PE	
	PVC		PA	
4	ABS		PMMA	
	PUR		GLASS	
	OTHER			

Rear wheel arch ornament assembly:

Applicable Model	JAECOO 7
Position Description	Rear wheel archs are located at the rear of vehicle, above the two rear wheels
Quantity	1 on each side
Weight (Kg)	0.21/pc
Main Material	ABP-2019
Fastener	Screw, clip
Number of Fasteners	12
Disassembly Tool	Cross tip screwdriver, clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.13 Front Wheel Protector

			0	
		PP	PE	
		PVC	PA	
		ABS	PMMA	
		PUR	GLASS	
		OTHER		

Front wheel protector:

Applicable Model	JAECOO 7
Position Description	Front wheel protectors are located at the front of vehicle, above the two front wheels
Quantity	1 on each side
Weight (Kg)	0.84/pc
Main Material	PP+EPDM
Fastener	Screw, clip
Number of Fasteners	28
Disassembly Tool	Cross tip screwdriver, clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.14 Rear Wheel Protector


	PP 📃	PE		
1 Hal	PVC	PA		
A A A A A A A A A A A A A A A A A A A	ABS	PMMA		
Well	PUR 📃	GLASS		
	OTHER			

Rear wheel protector:

Applicable Model	JAECOO 7
Position Description	Rear wheel protectors are located at the rear of vehicle, above the two rear wheels
Quantity	1 on each side
Weight (Kg)	0.79/pc
Main Material	PP+EPDM
Fastener	Snap fastener, screw, bolt
Number of Fasteners	24
Disassembly Tool	Socket wrench, cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.15 Instrument Panel




Instrument panel:

Applicable Model	JAECOO 7
Position Description	Front part inside the vehicle
Quantity	1
Weight (Kg)	10.16
Main Material	PP-LGF20, PP-T20, PP+EPDM-T20, PV, PC+ABS, HDPE
Fastener	Bolt, screw, clip
Number of Fasteners	/
Disassembly Tool	Socket wrench, clip remover, cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; recycling of mixed plastics through crushing and separation
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.16 Auxiliary Fascia Console




Auxiliary fascia console:

Applicable Model	JAECOO 7
Position Description	Front part inside the vehicle
Quantity	1
Weight (Kg)	6.52
Main Material	PP-LGF20, PP+EPDM-TD20, VMQ
Fastener	Bolt, screw
Number of Fasteners	16
Disassembly Tool	Socket wrench, cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.17 Glove Box




Glove box:

Applicable Model	JAECOO 7
Position Description	Glove box is located on the right side of instrument panel
Quantity	1
Weight (Kg)	1.29
Main Material	PP+EPDM-T20
Fastener	Clip
Number of Fasteners	2
Disassembly Tool	Flat tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.18 Front Windshield Assembly



rione windshield desembly.	
Applicable Model	JAECOO 7
Position Description	The glass between left and right A-pillars
Quantity	1
Weight (Kg)	13.54
Main Material	Glass
Fastener	-
Number of Fasteners	-
Disassembly Tool	Windshield removal tool kit
Disassembly Method	Use a windshield removal wire to cut through the adhesive material around the perimeter; disassemble using the windshield removal tool kit
Recycling Pathways	Tempered glass foam molding technology
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)

Front windshield assembly:




2.2.19 Front Door Glass Assembly

PP PE PE			
			PP PE PE PVC PA PA
		ABS PMMA	
		· · · · ·	
PUR GLASS			OTHER

Front door glass assembly:

Applicable Model	JAECOO 7
Position Description	On the front door
Quantity	2
Weight (Kg)	3.28/pc
Main Material	Glass
Fastener	Bolt
Number of Fasteners	4
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Tempered glass foam molding technology
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.20 Rear Door Glass Assembly


PP PE PE
PVC PA
ABS PMMA
PUR GLASS
OTHER

Rear door glass assembly:

Applicable Model	JAECOO 7
Position Description	On the rear door
Quantity	2
Weight (Kg)	2.57/pc
Main Material	Glass
Fastener	Clip
Number of Fasteners	2
Disassembly Tool	Cross tip screwdriver
Disassembly Method	Loosen the clips for disassembly
Recycling Pathways	Tempered glass foam molding technology
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.21 Front Triangular Block Assembly




Front triangular block assembly:

Applicable Model	JAECOO 7
Position Description	Front part of front left/right door
Quantity	2
Weight (Kg)	0.04/pc
Main Material	PMMA+ASA, POM-C
Fastener	-
Number of Fasteners	-
Disassembly Tool	-
Disassembly Method	Remove directly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.22 Rear Quarter Window Assembly




Rear quarter window assembly:

Applicable Model	JAECOO 7
Position Description	Both sides of the rear seat
Quantity	2
Weight (Kg)	1.85/pc
Main Material	Glass
Fastener	Clip
Number of Fasteners	14
Disassembly Tool	Clip remover
Disassembly Method	Using the plastic crow plate to pry off the clip
Recycling Pathways	Tempered glass foam molding technology
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.23 Panoramic Sliding Roof Assembly




Panoramic sliding cover assembly:

Applicable Model	JAECOO 7
Position Description	The middle of roof
Quantity	1
Weight (Kg)	22.9
Main Material	Glass
Fastener	Bolt
Number of Fasteners	16
Disassembly Tool	Socket wrench
Disassembly Method	Use a windshield removal wire to cut through the adhesive material around the perimeter; disassemble using the windshield removal tool kit
Recycling Pathways	Tempered glass foam molding technology
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.24 Rear Windshield Assembly





Rear windshield assembly:

Applicable Model	JAECOO 7
Position Description	On the back door
Quantity	1
Weight (Kg)	4.17
Main Material	Glass
Fastener	-
Number of Fasteners	-
Disassembly Tool	Windshield removal tool kit
Disassembly Method	Use a windshield removal wire to cut through the adhesive material around the perimeter; disassemble using the windshield removal tool kit
Recycling Pathways	Tempered glass foam molding technology
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.25 Engine Trim Cover







OTHER


Engine trim cover:

Applicable Model	JAECOO 7
Position Description	Above the engine
Quantity	1
Weight (Kg)	1.25
Main Material	PA66
Fastener	Bolt
Number of Fasteners	4
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.26 Air Filter Upper and Lower Housing






Air filter upper and lower housing:


Applicable Model	JAECOO 7
Position Description	In the engine compartment, in front of the battery
Quantity	1
Weight (Kg)	1.033
Main Material	PP-TD20, PUR
Fastener	Bolt
Number of Fasteners	3
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; reuse of rigid polyurethane foam through blending modification
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.27 Engine Sound Insulator Pad



Engine sound insulator pad:	
Applicable Model	JAECOO 7
Position Description	On the engine cover
Quantity	1
Weight (Kg)	0.38
Main Material	PU, non-woven cloth
Fastener	Clip, washer
Number of Fasteners	29
Disassembly Tool	Remove directly
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Reuse of rigid polyurethane foam through blending modification
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.28 Air Direct Pipe Assembly




Air direct pipe assembly:

Applicable Model	JAECOO 7
Position Description	In front of the air filter
Quantity	1
Weight (Kg)	0.21
Main Material	PP-KF03, BK501, PP-T20, plastic-coated steel wire, Q195
Fastener	Bolt, clamp
Number of Fasteners	3
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.29 Cooling Fan Assembly




Cooling fan assembly:

Applicable Model	JAECOO 7
Position Description	In front of the engine
Quantity	1
Weight (Kg)	1.033
Main Material	PA66-GF30, PA6-GF30, ST14
Fastener	Bolt
Number of Fasteners	4
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.30 Engine Inlet Pipe Assembly




|--|

Applicable Model	JAECOO 7
Position Description	Behind the cooling fan
Quantity	1
Weight (Kg)	0.5
Main Material	EPDM, PA66-GF30, 51CrV4, DC01
Fastener	Bolt
Number of Fasteners	3
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Reuse of crumb rubber made from waste rubber; reuse of reclaimed rubber from waste rubber; modified recycling of waste plastics; melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.31 Engine Outlet Pipe Assembly





Applicable Model	JAECOO 7		
Position Description	Behind the cooling fan		
Quantity	1		
Weight (Kg)	0.76		
Main Material	EPDM, PA66-GF30, 51CrV4, DC01		
Fastener	Bolt		
Number of Fasteners	3		
Disassembly Tool	Socket wrench		
Disassembly Method	Loosen the fasteners for disassembly		
Recycling Pathways	Reuse of crumb rubber made from waste rubber; reuse of reclaimed rubber from waste rubber; modified recycling of waste plastics; melting and reuse of metal materials		
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)		

Engine outlet pipe assembly:



2.2.32 Front Compartment Fuse and Relay Box Assembly






Front compartment fuse and relay box assembly:

Applicable Model	JAECOO 7
Position Description	In the front compartment, on the left side of the battery
Quantity	1
Weight (Kg)	13.8
Main Material	PA66-M30, PP-TD20
Fastener	Bolt
Number of Fasteners	4
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.33 Intake Hose Assembly



Intake hose assembly:

Applicable Model	JAECOO 7
Position Description	In the front compartment, on the right side of the battery
Quantity	1
Weight (Kg)	1.09
Main Material	E700, SUS430, PA6-GF30
Fastener	Bolt
Number of Fasteners	2
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.34 A-pillar Upper Trim Panel

	PP	PE DE
	PVC	PA PA
line l	ABS	PMMA
	PUR 📃	GLASS
÷	OTHER _	

A-pillar upper trim panel:

Applicable Model	JAECOO 7
Position Description	On the A-pillar
Quantity	1 on each side
Weight (Kg)	0.29
Main Material	PP+EPDM-T20
Fastener	Clip
Number of Fasteners	6
Disassembly Tool	Clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.35 A-pillar Lower Trim Panel


		6		6
	PP		PE	
	PVC		PA	
C. M.	ABS		PMMA	
	PUR		GLASS	
	OTHER			

A-pillar lower trim panel:

Applicable Model	JAECOO 7
Position Description	Under the A-pillar
Quantity	1 on each side
Weight (Kg)	0.15
Main Material	PP+PE-T5
Fastener	Clip
Number of Fasteners	6
Disassembly Tool	Clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.36 B-pillar Upper Trim Panel



B-pillar upper trim panel:

Applicable Model	JAECOO 7
Position Description	On the B-pillar
Quantity	1 on each side
Weight (Kg)	0.42/pc
Main Material	PP+EPDM-T20
Fastener	Screw, bolt
Number of Fasteners	6
Disassembly Tool	Cross tip screwdriver, socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.37 B-pillar Lower Trim Panel

	PP PE PE
	PVC PA
1 August 1 A	ABS PMMA
	PUR GLASS
ι	OTHER

B-pillar lower trim panel:

Applicable Model	JAECOO 7
Position Description	On the B-pillar
Quantity	1 on each side
Weight (Kg)	0.52/pc
Main Material	PP+PE-T5
Fastener	Clip
Number of Fasteners	8
Disassembly Tool	Clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.38 C-pillar Trim Panel


	PP PE PE
	PVC PA
A BAR D	ABS PMMA
X X	PUR GLASS
	OTHER

C-pillar trim panel:

Applicable Model	JAECOO 7
Position Description	On the C-pillar
Quantity	1 on each side
Weight (Kg)	0.77/pc
Main Material	PP+EPDM-T20
Fastener	Screw, clip
Number of Fasteners	12
Disassembly Tool	Cross tip screwdriver, clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.39 C-pillar Lower Trim Panel




C-pillar lower trim panel:

Applicable Model	JAECOO 7
Position Description	On the C-pillar
Quantity	1 on each side
Weight (Kg)	2.96/pc
Main Material	PP+PE-T5
Fastener	Screw, clip
Number of Fasteners	38
Disassembly Tool	Cross tip screwdriver, clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.40 Left Chassis Protector




Left chassis protector:

Applicable Model	JAECOO 7
Position Description	Underbody of the vehicle
Quantity	1
Weight (Kg)	1.808
Main Material	PET+PP
Fastener	Bolt, nut
Number of Fasteners	9
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.41 Right Chassis Protector





Right chassis protector:

Applicable Model	JAECOO 7
Position Description	Underbody of the vehicle
Quantity	1
Weight (Kg)	1.388
Main Material	PET+PP
Fastener	Nut
Number of Fasteners	8
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.42 Rear Left Chassis Protector






Rear left chassis protector:

Applicable Model	JAECOO 7
Position Description	Bottom of fuel tank
Quantity	1
Weight (Kg)	1.0595
Main Material	PET+PP
Fastener	Bolt, nut
Number of Fasteners	6
Disassembly Tool	Socket wrench
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.43 Front Doorsill Trim Panel




Front doorsill trim panel:

Applicable Model	JAECOO 7
Position Description	Under the front door
Quantity	1 on each side
Weight (Kg)	0.68/pc
Main Material	ABP-2019
Fastener	Clip
Number of Fasteners	22
Disassembly Tool	Clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.44 Rear Doorsill Trim Panel



Rear doorsill trim panel:

Applicable Model	JAECOO 7
Position Description	Under the rear door
Quantity	1 on each side
Weight (Kg)	0.84/pc
Main Material	ABP-2019
Fastener	Clip
Number of Fasteners	24
Disassembly Tool	Clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.45 Front Doorsill Pressure Plate Assembly


	PP PE PE
S &	PVC PA
T to D	ABS PMMA
	PUR GLASS
	OTHER

Front doorsill pressure plate assembly:

Applicable Model	JAECOO 7
Position Description	Under the front door
Quantity	1 on each side
Weight (Kg)	0.18/pc
Main Material	PP+PE-T5
Fastener	Clip
Number of Fasteners	6
Disassembly Tool	Clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.46 Rear Doorsill Pressure Plate Assembly




Rear doorsill pressure plate assembly:

Applicable Model	JAECOO 7	
Position Description	Under the rear door	
Quantity	1 on each side	
Weight (Kg)	0.23/pc	
Main Material	PP+PE-T5	
Fastener	Clip	
Number of Fasteners	6	
Disassembly Tool	Clip remover	
Disassembly Method	Loosen the fasteners for disassembly	
Recycling Pathways	Modified recycling of waste plastics	
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)	




2.2.47 Back Doorsill Trim Panel




Back doorsill trim panel:

Applicable Model	JAECOO 7
Position Description	Under the back door
Quantity	1
Weight (Kg)	0.56
Main Material	PP+PE-T5, PA6-GF20
Fastener	Screw, clip
Number of Fasteners	6
Disassembly Tool	Cross tip screwdriver, clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.48 Luggage Compartment Storage Box




Luggage compartment storage box:

Applicable Model	JAECOO 7
Position Description	Inside the luggage compartment
Quantity	1
Weight (Kg)	0.88
Main Material	EPP
Fastener	-
Number of Fasteners	-
Disassembly Tool	-
Disassembly Method	Remove directly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.49 Luggage Compartment Carpet Assembly




Luggage compartment carpet assembly:

Applicable Model	JAECOO 7
Position Description	Inside the luggage compartment
Quantity	1
Weight (Kg)	2.09
Main Material	Honeycomb cardboard, PET
Fastener	-
Number of Fasteners	-
Disassembly Tool	-
Disassembly Method	Remove directly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.50 Instrument Panel End Plate




Instrument panel end plate:

Applicable Model	JAECOO 7	
Position Description	On the instrument panel	
Quantity	1 on each side	
Weight (Kg)	0.13	
Main Material	PP+EPDM-T20, POM	
Fastener	Clip	
Number of Fasteners	14	
Disassembly Tool	Socket wrench	
Disassembly Method	Loosen the fasteners for disassembly	
Recycling Pathways	Modified recycling of waste plastics	
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)	




2.2.51 Instrument Panel Left Trim Panel




Instrument panel left trim panel:

Applicable Model	JAECOO 7
Position Description	On the instrument panel
Quantity	1
Weight (Kg)	1.39
Main Material	PC+ABS, PVC artificial leather
Fastener	Screw
Number of Fasteners	2
Disassembly Tool	Cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; recycling of mixed plastics through crushing and separation
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.52 Instrument Panel Right Trim Panel



Instrument panel right trim panel:

Applicable Model	JAECOO 7	
Position Description	On the instrument panel	
Quantity	1	
Weight (Kg)	2.1	
Main Material	PC+ABS	
Fastener	Clip	
Number of Fasteners	12	
Disassembly Tool	Clip remover	
Disassembly Method	Loosen the fasteners for disassembly	
Recycling Pathways	Modified recycling of waste plastics	
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)	



2.2.53 Sun Visor


PP PE PE
PVC PA
ABS PMMA
PUR GLASS
OTHER

Sun visor:

Applicable Model	JAECOO 7
Position Description	On the roof
Quantity	2
Weight (Kg)	0.48
Main Material	PP-T20, PC+ABS, glass
Fastener	Screw
Number of Fasteners	6
Disassembly Tool	Cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; after preprocessing the recycled glass, it is remelted in a furnace to manufacture glass containers, glass fibers, and other products
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.54 Inside Rear View Mirror



Inside rear view mirror:

Applicable Model	JAECOO 7
Position Description	On the roof
Quantity	1
Weight (Kg)	0.38
Main Material	PC+ABS, ADC12, glass
Fastener	Screw
Number of Fasteners	1
Disassembly Tool	Cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; after preprocessing the recycled glass, it is remelted in a furnace to manufacture glass containers, glass fibers, and other products; melting and reuse of metal materials
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.55 Front Door Inner Protector


	PP	PE
the same and	PVC	PA PA
1 years and	ABS	PMMA
	PUR	GLASS
-6	OTHER	

Front door inner protector:

Applicable Model	JAECOO 7
Position Description	On the front door
Quantity	2
Weight (Kg)	3.95
Main Material	PP+EPDM-T10, ABS, PVC
Fastener	Screw, clip
Number of Fasteners	24
Disassembly Tool	Cross tip screwdriver, clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; recycling of mixed plastics through crushing and separation
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.56 Rear Door Inner Protector




Rear door inner protector:

Applicable Model	JAECOO 7
Position Description	On the rear door
Quantity	2
Weight (Kg)	3.94
Main Material	PP+EPDM-T10, ABS, PVC P FR, PA6-GF30
Fastener	Screw, clip
Number of Fasteners	26
Disassembly Tool	Cross tip screwdriver, clip remover
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics; recycling of mixed plastics through crushing and separation
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.57 Interior Roof




Interior roof:

Applicable Model	JAECOO 7
Position Description	The upper area inside the vehicle
Quantity	1
Weight (Kg)	3.15
Main Material	Glass fiber, PC+ABS, GF15, PU foam sheet, PUR, PET fiber
Fastener	Mushroom clip, magnet clip, clip
Number of Fasteners	18
Disassembly Tool	-
Disassembly Method	Remove directly
Recycling Pathways	Modified recycling of waste plastics; recycling of mixed plastics through crushing and separation; reuse of rigid polyurethane foam through blending modification
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.58 Interior Front Carpet




Interior front carpet:

Applicable Model	JAECOO 7
Position Description	On the interior floor
Quantity	1
Weight (Kg)	6.49
Main Material	PU, EVA, PET
Fastener	-
Number of Fasteners	-
Disassembly Tool	-
Disassembly Method	Remove directly
Recycling Pathways	Reuse of rigid polyurethane foam through blending modification; modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.59 Interior Rear Carpet




Interior rear carpet:

Applicable Model	JAECOO 7
Position Description	On the interior floor
Quantity	1
Weight (Kg)	5.65
Main Material	EVA, PUR, PE
Fastener	-
Number of Fasteners	-
Disassembly Tool	-
Disassembly Method	Remove directly
Recycling Pathways	Modified recycling of waste plastics; reuse of rigid polyurethane foam through blending modification
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.60 Back Door Protector






Back door protector:

Applicable Model	JAECOO 7
Position Description	On the back door
Quantity	1
Weight (Kg)	2.23
Main Material	PP+EPDM-T10, PP+EPDM-T20
Fastener	Screw
Number of Fasteners	6
Disassembly Tool	Cross tip screwdriver
Disassembly Method	Loosen the fasteners for disassembly
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)




2.2.61 Surface Layer of Front Seats



Surface layer of front seats:

Applicable Model	JAECOO 7
Position Description	On the front seats
Quantity	1
Weight (Kg)	-
Main Material	PVC
Fastener	-
Number of Fasteners	-
Disassembly Tool	Scissors
Disassembly Method	Cut the C-clip and remove the steel wire from the cover
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.62 Cushion of Front Seats



 PP
 PE

 PVC
 PA

 ABS
 PMMA

 PUR
 GLASS


 OTHER
 Image: Construction of the second sec

Cushion of front seats:

Applicable Model	JAECOO 7
Position Description	On the front seats
Quantity	1
Weight (Kg)	-
Main Material	PUR
Fastener	-
Number of Fasteners	-
Disassembly Tool	Scissors
Disassembly Method	Cut the surface layer and pull to separate it from the cushion
Recycling Pathways	Reuse of rigid polyurethane foam through blending modification
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.63 Surface Layer of Rear Seats





Surface layer of rear seats:

Applicable Model	JAECOO 7
Position Description	On the rear seats
Quantity	1
Weight (Kg)	-
Main Material	PVC
Fastener	-
Number of Fasteners	-
Disassembly Tool	Scissors
Disassembly Method	Cut the C-clip and remove the steel wire from the cover
Recycling Pathways	Modified recycling of waste plastics
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)



2.2.64 Cushion of Rear Seats





Cushion of rear seats:

Applicable Model	JAECOO 7
Position Description	On the rear seats
Quantity	1
Weight (Kg)	-
Main Material	PUR
Fastener	-
Number of Fasteners	-
Disassembly Tool	Scissors
Disassembly Method	Cut the C-clip and remove the steel wire from the cover
Recycling Pathways	Reuse of rigid polyurethane foam through blending modification
Precautions for Disassembly	Wear protective equipment (goggles, gloves, etc.)

